MACHINE SETUP GUIDE

Touchscreen Model




Push the button on the electrical panel to enter the Setup Menu.





Interface



X Celebrity 12 - Matthew McCon

X Celebrity 09 - Donald Trump

DISPLAY

Select the currency sign

Select the currency decimals

The number of decimals shown with the currency.

Select the theme for the user interface

LANGUAGES

Select the languages and celebrities that the customers can choose from in the main menu.

1st language choice

This is the language which will be selected by default.

2nd language choice

> 3rd - 8th language choice



□ SCREENSAVER

Delay

Time in seconds before the screensaver becomes active when the machine is not being used.

You can disable the screensaver by deselecting the checkbox.



INFO SCREEN

Close time (seconds)

The amount of time after which the info screen is automatically closed.




Washing

X Celebrity 01 - Barack Obama

X Celebrity 02 - Morgan Free

4th language choice



Starting rate

The minimum amount of money required to start a washing session.

Washing time


The time a washing session takes based on the starting rate.

☐ Enable end decision

Give the customer the choice whether to buy more credits or to disinfect the tub. During this period the customer has the possibility to insert more money without having to pay the initial starting rate.

End decision time (sec)

Duration of the period for making the end decision.



☐ Stop time on pause

When checked the time will stop when the program is paused.

Clean tub duration (seconds)

Duration of the period for cleaning the tub.

Beep length (ms)

Length of the warning beep.

☐ Enable free wash

When free wash is enabled the machine can be used for free.

You can enable and disable 'stop time on pause' and 'free wash' by clicking the checkbox.















>>

Hardware



Present Card / Mobile

5

NAYAX

0

MAIN

□ NAYAX PAYMENT TERMINAL

Nayax start deposit

The amount of money that is transferred on usage.


Deposit add the end


The amount of money that is transferred on final choice.

You can disable the Nayax Payment Terminal by deselecting the checkbox.









☐ COIN VALIDATOR

Currency file

Choice of coins and token that will be accepted and their value.

NOTE: <u>DO NOT</u> select another currency file if we programmed a custom Token for your Company. This will erase the Token!

This is the Dog Wash Token and it's value.

You can disable the Coin Validator by deselecting the checkbox.

☐ BANKNOTE READER

Currency file

Choice of banknotes that will be accepted and their value.

You can disable the Banknote Reader by deselecting the checkbox.

>>

Misc

X

Logging Server address http://178.62.215.158/api/management/ Specify the address of the server used for logging, e.g. http://logging.example.com API key aead50539d734e7d814ac1e8fc135c65 Specify the API key used for identifying the machine. Save Exit

LOGGING

Server address

Specify the address of the server used for logging.

API key

Specify the API key used for identifying the machine when using the Dog Wash App.

Statistics Statistics Number of washes 0 Cash payments € 0.00 Nayax payments € 0.00 Total revenue € 0.00 All-time number of washes 0 All-time revenue € 0.00 Reset all-time statistics

Statistics

STATISTICS

Statistics screen

On this screen the owner can monitor:

- Number of washes
- Cash payments
- Navax payment
- Nayax paymentsToken payments

Bonus Feature

SECRET DISINFECT FUNCTION

Information screen

If you enter the information screen you can click on the 'shiny stars' icon to directly enter the 'disinfect mode'. This is a hidden feature that gives the owner the possibility to quickly clean the washtub without having to insert money or enter the 'free wash' mode.



Contact

iClean International B.V.

Keizersveld 58 5803 AN Venray The Netherlands

- +31 (0) 478 51 79 79
- info@icleandogwash.com
 www.icleandogwash.com